

Firmware Update Procedures

HS-4000's LCD Monitor

This document provides procedures for updating the LCD Monitor firmware for the HS-4000 4K 8-Channel Portable Video Streaming Studio. The firmware update of the HS-4000 LCD Monitor can be done by connecting your HS-4000 to a laptop or PC.

Updating the LCD Monitor Firmware for the HS-4000

What items you should prepare before updating the firmware

- The latest HS-4000 LCD Monitor firmware update zip file x1.
The latest firmware zip file can be downloaded from the HS-4000 product page of the Datavideo official website <https://www.datavideo.com/product/HS-4000>. After the downloaded firmware zip file is unzipped, you can see one firmware file and the firmware update must be done by the Firmware Update Web UI
➤ **GB961-DVT-R95-V17-BE0S(0610 7603)**
- HS-4000 x 1
- 56V power adapter x 1
- Laptop or PC x 1
- RJ-45 Ethernet cable x 1

This document describes how to perform firmware update on a **Windows** computer.

System Connection Diagram



[Checking the Firmware Version](#)

[Updating the Firmware](#)


Checking the Firmware Version

1. Please make sure that the 56V power adapter is connected to your HS-4000. After that, please press the power button which is located on the rear panel of the HS-4000 to turn on the power.


Note: You need to use the control panel of the LCD monitor to do the firmware update. The control panel of the LCD panel is shown in the following diagram.





2. Please press the “MV” button from the HS-4000 control panel. After that, the MultiView Screen will be shown on the LCD Panel.




3. Please press the "MENU" button from the control panel. After that, the OSD MENU will be shown on the LCD.



4. Please press the "DOWN" button  on the control panel to select the "SYSTEM" option, and then press the "ENTER" button .

5. After entering the "SYSTEM" page, you can see the current firmware version of the HS-4000 LCD monitor. In this example, the firmware version is "17".




Updating the Firmware

1. Please make sure that the 56V DC power cable is connected to the HS-4000.
2. Please connect an Ethernet cable from the "LAN/DVIP" port on the rear panel of the HS-4000 to the Ethernet port of your laptop or PC.
3. Please turn on the power of the HS-4000. After the HS-4000 turns on, please press the



"MV" button from the control panel. And then the MultiView screen will be shown on the LCD monitor of the HS-4000.





4. Please press the "MENU" button from this control panel to open the OSD Menu. After that,




use the "DOWN" button to select the "SYSTEM" option. Once the "SYSTEM" is selected, please press



the "ENTER" button from the control panel to enter the "SYSTEM" page. And then you will see the IP address of the LCD Monitor driver board, in this example, it is "169.254.1.1".



5. Please set the IP address of your laptop or PC to be within the same LAN as the HS-4000 Monitor driver board.




6. Please enter the IP address of the HS-4000 LCD Monitor driver board into the address bar of your web browser to open the firmware update Web UI. In this example, the IP address is "169.254.1.1".


The screenshot shows a web browser window with the address bar displaying "169.254.1.1". The web page has a blue header with the "datavideo" logo and "NetWork" text. The main content area is divided into two panels. The left panel, titled "Network Information", contains input fields for IP Address (169, 254, 1, 1), Mask (255, 255, 0, 0), and GateWay (169, 254, 1, 1). The right panel, titled "Firmware Upload", shows "MD5 Sum:" and "Select the File:" with a "Choose File" button and "No file chosen" text. Below this is an "Update Firmware" button.

7. Please press the "Choose File" button to select the firmware file, and then press the "Open" button.

This screenshot is identical to the previous one, but the "Choose File" button in the "Firmware Upload" section is highlighted with a red rectangle to indicate it should be clicked.




8. Please press the "Update Firmware" button to start the firmware update procedure.




The screenshot shows the datavideo NetWork web interface. On the left, the 'Network Information' section contains input fields for IP Address (169.254.1.1), Mask (255.255.0.0), and GateWay (169.254.1.1). On the right, the 'Firmware Upload' section shows the MD5 Sum and a file selection area. A file named 'GB961-DVT...10 7603).bin' is selected. Below the file selection, the 'Update Firmware' button is highlighted with a red rectangle.

9. After the popup reminder is shown, please press "OK" to start the firmware update.




This screenshot shows the same interface as the previous one, but with a warning popup dialog box in the center. The dialog is titled '169.254.1.1 says' and contains the text: 'Warning: Please do not click any item on this Page while uploading. The MD5 Sum will be updated when the process has been done. Please click the button to start uploading!'. An 'OK' button is highlighted with a red rectangle.




This screenshot shows the datavideo NetWork interface after the warning popup has been closed. The 'Update Firmware' button is still visible in the 'Firmware Upload' section.




10. During the firmware update, there is no picture on the LCD, the LED of the KEY Board will turn off and on again, and then the MultiView screen will appear on the LCD. It will cost about 1 minute and 20 seconds to finish the firmware update, please do not disconnect the network and power supply during the update.

11. After the message below is shown on the firmware update Web UI, it means that the firmware update procedure is done successfully.



12. Please press the “PWR” key  on the control panel to turn off the LCD. After that, please reboot the HS-4000 by turn off and turn on the power button on its rear panel. Finally, please press the “PWR” key to turn on the LCD power.

Note: When pressing the power button on the rear panel of the HS-4000, there is a reminder “Do you want to shutdown the system?” that will be shown on the 5” LCD screen on the control panel, please press “Yes” and then the power of the HS-4000 will be turned off.

13. Please press the “MENU” key  on the control panel to open the OSD Menu. After that, please press the “DOWN” key  to select the “SYSTEM” option and then press the “Enter” key  to enter the “SYSTEM” page. And then you can see the updated firmware version.