

Firmware Update Procedure for Customer

Datavideo usually releases new firmware containing new features or reported bug fixes from time to time. Customers can either download the DAC-8PA firmware as they wish or contact their local dealer or reseller for assistance.

This document outlines the firmware upgrade process which should take ***approximately 10 minutes to complete***. The existing DAC-8PA settings should persist through the ***firmware upgrade process, which should not be interrupted once started*** as this could result in a non-responsive unit.

Successful firmware upgrade on DAC-8PA requires:

- The latest firmware file, which can be obtained from your local Datavideo dealer or office.
- A PC or a laptop.
- A USB Cable

Step 1: Please download the latest DAC-8PA firmware “DAC-8PA FW TOOL V1.02” from Datavideo’s official website www.datavideo.com.

Step 2: Please install the DAC-8PA FW Tool.exe in your PC or laptop and then please open the software.

Step 3: Please connect the DAC-8PA to the power.

Step 4: Please press the “READ” button and then the software version will be shown.

Step 5: Please press the “SMPTE” or “EBU” button to set the Audio Level standard.

